

Wide variety of stitch patterns



80 Sewing Patterns

Sew Comfortably!



The needle threader easily threads the needle and allows you to start sewing quickly.

Start/Stop Button



The color of the

Start / Stop

button indicates

the status of the

machine.

Ready to start or while sewing

[Red]
Not ready to start

START [Orange]

In bobbin winding condition



HZL-H series can sew a lock stitch at the beginning and end of sewing. There are two types of lock stitch, reverse stitch and reinforcement stitch.

Direct Pattern Selection



There are 6 types of stitch patterns, from which you can choose one by directly pushing the pattern button.

Sew Firm!

Needle Up/Down Position Button



Press the button to change up/down position of needle instantly. Also you can change needle stop position and can even sew a half stitch.

Buttonhole



HZL-H series sews the buttonhole automatically according to the size of the button.

Presser Foot Pressure



Easy to Use!



You can change the size of stitch patterns as well as the needle positions.



HZL-70HW-B

■ SPECIFICATIONS

Sewing Speed: Max. 800sti/min Needle: HA×1 #9~#18 Dimensions: 400(W)×290(H)×188(D)mm Weight (machine only): 5.8kg

Accessories



A:Standard Presser Foot B:Zipper Foot C:Decorate Stitch Foot D:Overcasting Foot E:Blind Stitch Foot F:Button Sewing Foot G:Buttonhole Foot H:Seam Ripper/ Brush I:Screwdriver (S) J:Screwdriver(L-shape) K:Auxiliary Spool Pin L:Bobbin (3x) M:Quilit Guide N:Spool Cap(Large) O:Spool Cap(Small) P:Spool Pin Felt Q:Pack of Needles(3x)



Hard Case F



Other Features

- Free Arm
- Drop-in Bobbin
- Drop Feed
- Easy to Start Sewing Thick Fabrics
- Button Sewing



JUKI CENTRAL EUROPE Sp. z o.o. ul. Poleczki 21, 02-822 Warsaw, Poland

Tel.: +48 22 545 04 00 / Fax: +48 22 545 04 11

www.jukieurope.com / www.facebook.com/JukiSewlt / e-mail: juki@juki.pl